


VECTOR2 Installation Manual



SABS | DESIGN EXCELLENCE AWARDS 2009

LINEAR SWING GATE OPERATORS

Company Profile



1986

1990

1995

1999

Centurion Systems
Today

In-house
R & D
development
team

Manufacture to
international
quality standard
ISO 9001:2008



100%
testing of
products

After-sales
technical support
from 07h00 - 18h00
Monday to Friday



Sales and technical support
to over 50 countries
worldwide

CENTURION SYSTEMS (Pty) Ltd reserves the right to make changes to the products described in this manual without notice and without obligation of **CENTURION SYSTEMS (Pty) Ltd** to notify any persons of any such revisions or changes. Additionally, **CENTURION SYSTEMS (Pty) Ltd** makes no representations or warranties with respect to this manual.

No part of this document may be copied, stored in a retrieval system or transmitted in any form or by any means electronic, mechanical, optical or photographic, without the express prior written consent of **CENTURION SYSTEMS (Pty) Ltd**.



Contents



Mechanical Setup	page 1
Electrical Setup	page 2
Commissioning and Handover	page 2



IMPORTANT SAFETY INSTRUCTIONS	page 3
--------------------------------------	--------

1. Declaration of Conformity	page 5
2. General Description	page 6
• Lightning Protection	page 7
3. Icons Used in this Manual	page 7
4. Specifications	page 8
• Physical Dimensions	page 8
• Technical Specifications	page 9
• Control Card	page 10
• Power Supply	page 10
• Power Supply, Control Box and Control Card Assembly 2	page 10
• Allowable Gate Mass	page 11
5. Product Identification	page 12
6. Required Tools and Equipment	page 14
7. Preparation of Site	page 15
• General Considerations for the Installation	page 15
• Strength of the Pillar	page 16
• Strength of the Gate and Gate Bracket	page 19
• Mechano Kit Installation Options	page 20
• High-Security Kit Installation Options	page 21
8. Cabling Requirements	page 22
9. Critical Installation Checklist	page 23
10. Operator Installation	page 24
• Determine the Gate Bracket Position	page 25
• Fasten Gate Bracket to Gate	page 27
• Adjust Origin Clamp	page 28
• Inward Swing Gate Setup	page 29
• Outward Swing Gate Setup	page 32
11. Determine Gate Swing Angle	page 35
12. Allowable Wind Load	page 36

13. Electrical Setup	page 37
• Secure Control Box to Wall	page 37
• Connecting all Wiring	page 37
• Setting the Limits	page 38
14. Wiring Diagram for Closing Safety Beams	page 40
15. Wiring Diagram for Opening Safety Beams	page 41
16. Wiring Diagram for External Radio Receiver and Loop Detector	page 42
17. Wiring Diagram for Other Inputs	page 43
18. Wiring Diagram for Master Motor (MTRM)	page 44
19. Wiring Diagram for Slave Motor (MTRS)	page 45
20. Charger and Pillar Light Connections	page 46
21. Solar Panel Wiring	page 47
22. Setting up Additional Features	page 48
23. Menu Navigation Map	page 48
24. Controller Features	page 52
25. Factory Defaults Schedule	page 63
26. Description of Terminal Functions	page 69
27. Diagnostics	page 72
• Diagnostic LEDs	page 72
• Gate Status LED Indication	page 72
• LCD Display	page 73
• Buzzer Feedback	page 74
28. Installation Handover	page 75



Mechanical Setup

These quick steps are for the experienced installer who needs a checklist to get a standard installation up and running in the minimum of time.

Detailed installation features and functions are referred to later in this manual.



Gather required tools and equipment Page 14



Heed necessary site considerations Page 15



Check cabling requirements Page 22



Mount the wall bracket Page 25



Install motor and link to gate Page 25



Mount controller enclosure and connect all wiring Page 37



Fit mechanical endstops Page 38

Electrical Setup



Connect all wiring
Run setup routine

Page 40



Commissioning and Handover



Commission system

Page 62



Carry out professional handover to
client

Page 74





IMPORTANT Safety Instructions

ATTENTION

To ensure the safety of people, it is important that you read all the following instructions.

Incorrect installation or incorrect use of the product could cause serious harm to people.

The installer, being either professional or DIY, is the last person on the site who can ensure that the operator is safely installed, and that the whole system can be operated safely.

Warnings for the installer

CAREFULLY READ AND FOLLOW ALL INSTRUCTIONS before beginning to install the product.

- All installation, repair, and service work to this product must be carried out by a suitably qualified person
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety
- Do not activate your gate unless you can see it and can determine that its area of travel is clear of people, pets, or other obstructions
- **NO ONE MAY CROSS THE PATH OF A MOVING GATE.** Always keep people and objects away from the gate and its area of travel
- **NEVER LET CHILDREN OPERATE OR PLAY WITH THE GATE CONTROLS**
- Secure all easily-accessed gate opener controls in order to prevent unauthorised use of the gate
- Do not in any way modify the components of the automated system
- Do not install the equipment in an explosive atmosphere: the presence of flammable gasses or fumes is a serious danger to safety
- Before attempting any work on the system, cut electrical power to the operator and disconnect the batteries
- The mains power supply of the automated system must be fitted with an all-pole switch with contact opening distance of 3mm or greater. Use of a 5A thermal breaker with all-pole circuit break is recommended



- Make sure that an earth leakage circuit breaker with a threshold of 30mA is fitted upstream of the system
- Never short-circuit the battery and do not try to recharge the batteries with power supply units other than that supplied with the product, or by CENTURION
- Make sure that the earthing system is correctly constructed, and that all metal parts of the system are suitably earthed
- Safety devices must be fitted to the installation to guard against mechanical movement risks such as crushing, dragging and shearing
- It is recommended that at least one warning indicator light be fitted to every system
- Always fit the warning signs visibly to the inside and outside of the gate
- The installer must explain and demonstrate the manual operation of the gate in case of an emergency, and must hand the User Guide/Warnings over to the user
- Explain these safety instructions to all persons authorised to use this gate, and be sure that they understand the hazards associated with automated gates
- Do not leave packing materials (plastic, polystyrene, etc.) within reach of children as such materials are potential sources of danger
- Dispose of all waste products like packaging materials, worn-out batteries, etc., according to local regulations
- Always check the obstruction detection system, and safety devices for correct operation
- CENTURION does not accept any liability caused by improper use of the product, or for use other than that for which the automated system was intended
- This product was designed and built strictly for the use indicated in this documentation. Any other use, not expressly indicated here, could compromise the service life/operation of the product and/or be a source of danger
- Everything not expressly specified in these instructions is not permitted



1. Declaration of Conformity

Manufacturer

Centurion Systems (Pty) Ltd
Unit 13 Production Park
Intersection of Newmarket Road and Epsom Avenue
North Riding
Gauteng
South Africa

Declares that the product

Product name: **VECTOR2** Swing gate operator

Product options: All variants

Conforms with the following specifications

Safety: SANS 60335-1:2007
IEC 60335-1:2006

Emissions: CISPR 22 CLASS B: Radiated emissions – 30MHz to 1000MHz
CISPR 22 CLASS B: Conducted emissions – 150 KHz to 30MHz

Immunity: IEC 61000-4-2 – Electrostatic discharge
IEC 61000-4-3 – Radiated immunity – 80MHz to 1000MHz
IEC 61000-4-4 – Electrical fast transients/burst
IEC 61000-4-5 – Surge immunity test
IEC 61000-4-6 – Conducted immunity – 150KHz to 80MHz
IEC 61000-4-8 – Power frequency magnetic field
IEC 61000-4-11 – Voltage dips and interruption

Standard to which conformity is declared

IEC 60335-1:2006	Safety
IEC 61000-6-3	Emissions
IEC 61000-6-1	Immunity

Signed at North Riding, South Africa on June 21, 2010



Ian Rozowsky
Research & Development Director

2. General Description

The **VECTOR2** operator has been designed to safely and cost-effectively automate a wide variety of swing gates, from single light-domestic swing gates to heavy industrial double swing gates.

The fail-safe and fully redundant Position and Collision Detection system has been designed and tested to set the standard in safety of operation and to provide an unparalleled level of reliability and durability in operation.

The gate Travel Limits are managed by a sealed double-redundant opto-electronic system that has been designed not only to ensure ultra-reliable operation, but also to ensure precise position and trajectory control. This enables very accurate and reliable collision detection to ensure safe operation even under trying conditions.

The **VECTOR2** control card has been designed to be easy and intuitive to use, with helpful instructions on the status of the operation being given both during and after the installation. It also has a built-in diagnostic procedure that can verify every aspect of the control card onsite.

Some of the advanced features offered by the **VECTOR2** controller are:

- Fully automated single-button Limit Setup for single and double swing gates
- Full graphics LCD display provides an intuitive user interface with built-in diagnostics to speed up and simplify the installation process
- Separate safety inputs for infrared beams on both the closing and opening directions of the gate
- Advanced closed-loop speed control to maintain safe and reliable operation on inclined gates under windy conditions
- Fully configurable gate Run Profiles
- Selectable and adjustable Autoclose with pushbutton override
- Pedestrian (Partial) opening with automatic closure
- Free-exit input
- Positive Close Mode
- Multiple Modes of Operation
- Solenoid lock drive output up to 2A
- Holiday Lockout
- A status LED output to indicate the gate status remotely
- Pillar Light control
- Leaf delay is selectable for either gate leaf
- Onboard CENTURION receiver with selective adding and deleting of remotes

Lightning Protection

The **VECTOR2** electronic controller utilises the same proven surge protection philosophy that is used in all CENTURION products. While this does not guarantee that the unit will not be damaged in the event of a lightning strike or power surge, it greatly reduces the likelihood of such damage occurring. The earth return for the surge protection is provided via the mains power supply earth. In order to ensure that the surge protection is effective, it is essential that the unit is properly earthed.

3. Icons Used in this Manual



This icon indicates tips and other information that could be useful during the installation.



This icon denotes variations and other aspects that should be considered during installation.



This icon indicates warning, caution or attention! Please take special note of critical aspects that MUST be adhered to in order to prevent injury.

4. Specifications

Physical Dimensions




FIGURE 1. V400 OVERALL DIMENSIONS




FIGURE 2. V500 OVERALL DIMENSIONS

Technical Specifications

	VECTOR2 400	VECTOR2 500
Input voltage	90V*/ 220V - 240V AC ± 10%, 50Hz	
Motor voltage	12V DC	
Motor power supply	Battery-driven (standard capacity - 7Ah) [†]	
Battery charger [★]		
Domestic [Ⓢ]	CP84E - 800mA @ 13.8V	
Light-industrial [Ⓣ]	CP84SM - 2A @13.8V	
Current consumption (mains)	60mA [Ⓢ] / 170mA [Ⓣ]	
Current consumption (motor at rated load)	15A - maximum	
Operator push force - maximum	250kgf	
Operator stroke	400mm	500mm
Piston extension/retraction speed	27mm/sec	
Typical gate opening time [‡]	<14 sec	<17 sec
Manual override	Key release	
Maximum number of operations per day	100 [Ⓢ] /250 [Ⓣ]	
Duty cycle - mains present ^{***}	25% [Ⓢ] /50% [Ⓣ]	
Operations in standby with 7Ah battery [‡]		
Half day	70	
Full day	58	
Collision sensing	Electronic	
Controller solenoid output rating	2A DC	
Operating temperature range	-15°C to +50°C	
Onboard receiver type	CENTURION code-hopping multichannel	
Receiver code storage capacity	64 transmitter buttons	
Receiver frequency	433MHz	
Mass of unit packed (excluding battery)		
Single kit	8.5kg	9kg
Double kit	14kg	15kg
Degree of protection	IP54	

* Applies to CP84SM light-industrial unit only

† Can increase battery capacity for longer standby times

★ Can operate off a solar supply, consult Centurion Systems (Pty) Ltd for assistance

Ⓢ Domestic

Ⓣ Light-industrial

‡ Assumes full stroke of operator is used

⌘ Based on 25°C ambient temperature and unit not in direct sunlight

*** Based on an operator push force of less than 50% of rated

‡ Based on double kit excluding Infrared Safety Beams

* Assumes a 90° opening gate and optimum mounting position

Control Card

Maximum motor current per channel	15A (fused)
Maximum input voltage	14.4V DC
Standby current draw	48mA
Maximum solenoid current draw	2A DC
Maximum auxillary output current	3A (PTC)
Collision detection	Current sense and redundant optical
Position and trajectory	Redundant optical
Temperature range	-20°C to +60°C

Power Supply

	7Ah, 12V, CP84E (Domestic)	7Ah, 12V, CP84SM2A (Light-industrial)
Nominal input voltage	220V-240V AC ±10% @ 50Hz	90V-240V AC ±10% @ 50Hz
AC current draw (maximum)	60mA	170mA
Temperature range	-20°C to +60°C	-20°C to +60°C
Battery charger amperage output (dependant on PSU input voltage)	0.8A @ 13.8V	90V AC Input: 1.2A @ 13.8V 240V AC Input: 2.2A @ 13.8V

Power Supply, Control Box and Control Card Assembly

	7Ah, 12V, CP84E (Domestic)	7Ah, 12V, CP84SM 2A (Light-industrial)
Boxed shipping weight (excluding batteries):	2.7kg	2.6kg
Degree of protection	IP55	IP55

Allowable Gate Mass

Maximum allowable gate mass for the V400 operator:

Gate swing angle	Up to 1.5 metres	Up to 2 metres	Up to 2.5 metres	Up to 3 metres (#1)	Up to 3.5 metres (#1)	Up to 4 metres (#1)
90°	500kg	500kg	500kg	360kg	260kg	200kg
100°	500kg	500kg	388kg	160kg	190kg	150kg
110°	500kg	306kg	198kg	130kg	Not recommended	
120°	180kg	100kg	65kg			

#1 - An electric lock must be fitted to secure gate in closed position

Maximum allowable gate mass for the V500 operator:

Gate swing angle	Up to 1.5 metres	Up to 2 metres	Up to 2.5 metres	Up to 3 metres (#1)	Up to 3.5 metres (#1)	Up to 4 metres (#1)
90°	750kg	750kg	750kg	550kg	410kg	310kg
100°	750kg	750kg	600kg	420kg	310kg	230kg
110°	750kg	500kg	320kg	220kg	Not recommended	
120°	310kg	170kg	110kg			

#1 - An electric lock must be fitted to secure gate in closed position

5. Product Identification




FIGURE 3A. PRODUCT IDENTIFICATION

- | | |
|---|--------------------------------------|
| 1. Wall bracket (standard) | 7. Gate bracket pin |
| 2. Wall bracket pin | 8. Gate bracket |
| 3. VECTOR2 gate operator (complete assembly) | 9. Stainless steel cap screw M6 x 25 |
| 4. 12mm snap ring | 10. Origin body |
| 5. Gate warning decal | 11. Stainless steel M6 nut |
| 6. Gate operator keys* | 12. 14mm snap ring |

* Keys are specific to each operator - key number must be recorded




FIGURE 3B. CONTROL BOX INCLUDING CHARGER AND CONTROLLER

- | | |
|--|------------------------------|
| 1. 12V 7.2Ah Battery (user supplied - not part of kit) | 4. CENTURION remote controls |
| 2. VECTOR2 controller with built-in receiver | 5. User Guide |
| 3. Charger | 6. Installation Manual |
| | 7. Control Box |




FIGURE 3C. WALL ADAPTOR KIT

- | | |
|--|-------------------------------|
| 1. VECTOR2 Wall Adaptor Kit packing leaflet | 3. Wall adaptor plate |
| 2. M10 hexagon nuts | 4. M10 x 20 countersunk screw |




FIGURE 3D. HIGH-SECURITY KIT

- | | |
|---|---------------------------------|
| 1. VECTOR2 High-security Kit packing leaflet | 3. Wall bracket (high-security) |
| 2. Padlocks | |




FIGURE 3E. MECHANO KIT

- | | |
|---|---|
| 1. VECTOR2 securing plate (short) | 4. M10 x 35 bolt |
| 2. VECTOR2 Mechano Kit packing leaflet | 5. VECTOR2 securing plate (long) |
| 3. M10 x 35 bolt | |




FIGURE 3F. GATE ADAPTOR KIT

- | | |
|--|--------------------------------|
| 1. VECTOR2 Gate Adaptor Kit packing leaflet | 3. Gate bracket spreader plate |
| 2. M6 x 16 countersunk cap screw | 4. M6 hexagon nuts |

6. Required Tools and Equipment



FIGURE 4

7. Preparation of Site

General Considerations for the Installation

- Always recommend the fitment of additional safety equipment such as safety edges and Safety Beams, for additional protection against entrapment or other mechanical risks
- Check that no pipes or electrical cables are in the way of the intended installation
- Check that enough space is available for the gate operator with the gate in the required open position (see Figures 4 and 5)
- Check the strength of the mounting pillar and fit a Wall Adaptor Kit where needed
- If the swing gate leaf is longer than 2.5 metres, ensure that a lock can be fitted
- Never fit the operator on the outside of the gate, where the public has access to it (follow the instructions for an outward opening swing gate, if required)
- For greater security consider fitting the optional High-security Kit

Install the gate operator only if:

- It will not pose a hazard to the public
- There is sufficient clearance to a roadway and/or public thoroughfares
- The installation will meet all municipal and/or local authority requirements once completed
- The gate mass, leaf width, allowable wind loading and application is within the operator specifications (refer to the specification tables)
- The gate is in good working order, meaning:
 - that it swings freely;
 - does not move on its own if left in any position;
 - each gate leaf is strong and rigid
 - it can be installed to have sufficient clearance between moving parts when opening and closing to reduce the risk of personal injury and entrapment
 - pushbuttons or keyswitches, when required, can be positioned so that the gate is in line of sight

Gate opening 90° or less

Operator	Wall (minimum) ^{**}	Pillar (maximum)
V400	150mm	250mm
V500	150mm	335mm




FIGURE 5

Gate opening 110°

Operator	Wall (minimum) [❖]	Pillar (maximum) [☆]
V400	150mm	145mm
V500	150mm	210mm




FIGURE 6

Tables are based on gates shorter than 2.5 metres

- For gates 2.5 metres to 3.0 metres long, reduce the maximum pillar thickness by 20mm
- For gates 3.0 metres to 3.5 metres long, reduce the maximum pillar thickness by 40mm
- For gates 3.5 metres to 4.0 metres long, reduce the maximum pillar thickness by 60mm

❖ The typical minimum wall clearance required to fit the operator

☆ The maximum allowable pillar thickness on which to fit the operator

Strength of the Pillar



For reliable operation it is important to ensure that the way the operator is secured to the wall takes into account the strength of the pillar, the size of the gate, and how frequently the gate will be used:

High-security Kit together with a Wall Adaptor Kit

This mounting is highly recommended for all light-industrial gates, or for heavy gates of any length.

Alternatively it should be considered for use on pillars of low or unknown strength.




FIGURE 7

High-security Kit

This mounting works well for heavy gates shorter than about two metres in single household domestic applications.

Alternatively it should be considered for use on pillars of low or unknown strength.




FIGURE 8

Standard bracket

This mounting method is typically used on light- to medium-weight domestic gates that are about 1.5 metres long, and that are mounted on pillars of average strength.



The means used to secure the bracket to the pillar is as important as the bracket itself.




FIGURE 9

Through wall

Applications:

- Pre-fabricated walling
- For heavy gates operating frequently




FIGURE 10

Chemical anchors

Applications:

- Masonry pillars
- Frequent use




FIGURE 11

Welding

Applications:

- Lighter gates
- Domestic




FIGURE 12

Sleeve anchors

Applications:

- Lighter gates
- Domestic




FIGURE 13

RAWL bolts

Applications:

- Very light
- Domestic




FIGURE 14

Strength of the Gate and Gate Bracket

The Gate Adaptor Kit both strengthens the connection to the gate, and also allows for more flexibility when mounting the bracket to the gate:

Welding Gate Adaptor Kit

Applications:

- Light-industrial
- Heavy gates
- Frequent use




FIGURE 15

Through-bolts Gate Adaptor Kit

Applications:

- Light-industrial
- Heavy gates
- Frequent use




FIGURE 16

Welding

Applications:

- Domestic
- Medium gates
- Frequent use




FIGURE 17

Through-bolts (high-tensile)

Applications:

- Domestic
- Light gates
- Infrequent use




FIGURE 18



TEK screws and mild steel bolts are not recommended.

Mechano Kit Installation Options

This kit is useful when fitting **VECTOR2** to existing installations, and also makes adjustments easier when doing new installations.




FIGURE 19. INSTALLATION WHEN THE PILLAR IS WIDE




FIGURE 20. INSTALLATION WHEN THE PILLAR IS ON AN IRREGULAR SURFACE




FIGURE 21. INSTALLATION ON A PALISADE FENCE




FIGURE 22. INSTALLATION ON AN ANGLED WALL

High-Security Kit Installation Options




FIGURE 23. INSTALLATION WHEN THE PILLAR IS WIDE




FIGURE 24. INSTALLATION WHEN THE PILLAR IS ON AN IRREGULAR SURFACE



FIGURE 25. INSTALLATION ON A PALISADE FENCE




FIGURE 26. INSTALLATION ON AN ANGLED WALL

8. Cabling Requirements




FIGURE 27. CABLING REQUIREMENTS

Legend

1. 90V[‡]/220V - 240V AC mains cable via mains isolator[★] switch (3 core LNE 0,5mm²)[★], or low-voltage 16V AC battery charger supply[‡] (2 core 1,5mm²).
2. Intercom cable (n1 + 6 core) to house.
3. Master motor (MTR M) or Slave motor (MTR S) cable (minimum, 2 core 2mm² + 4 core 0,5mm² multi-stranded) see note[⊛].
4. Optional radio receiver cable (3 core 0,5mm² multi-stranded, optional)[⊛].
5. Optional Pedestrian Keyswitch (2 core 0,5mm² multi-stranded) or optional keypad (3 core 0,5mm² multi-stranded).
6. Optional infrared Safety Beams (3 core 0,5mm² multi-stranded or 4 core 0.5mm² for CE compliance.)
7. Optional intercom cable (n2+2 core 0,5mm² multi-stranded) to gate station.
8. Optional electric lock (2 core 0.5mm²).
9. Optional Pillar Light cable (3 core, size according to power regulations).
10. Optional ground loop for free-exit (1 core 0.5mm² multi-stranded - silicone-coated)[‡]

[‡] Applicable to CP84SM charger only

[★] Mains isolator must be fitted less than 1 metre from controller

[☆] Increase cable thickness if Pillar Lights are to be installed

[‡] Screened cable is always recommended to provide better protection against lightning - earth one end of screening

[⊛] Domestic charger only

[⊛] For optimum range an external receiver can be mounted on the wall

[‡] CENTURION has custom **VECTOR2** cable available. Order reference: CABLEVEC68. Consult manufacturer of loop detector for specific details



- **All cables must be routed in conduit unless underground cable is being used**
- **Mains isolator must be less than one metre from the operator**
- **Safety Beams are always recommended**

9. Critical Installation Checklist

The following is a list of critical requirements that must be adhered to in order to ensure reliable operation of your **VECTOR2** operators:

- Ensure that the wall bracket is securely anchored
- Make sure that the actuator's maximum stroke is being utilised
- Only use **VECTOR** cable for the installation
- Leave a 350mm loop in the cable (refer to page 37)
- Fit an electromechanical or an electromagnetic gate lock if the leaf width is greater than three metres
- Ensure that the opening and closing angles conform to the installation guidelines
- Ensure that your gate and operators are equipped to deal with wind loading (refer to the table on page 36)
- Ensure that fixed mechanical endstops are fitted in the fully open position for outward swinging gates

10. Operator Installation

1. Determine the gate opening angle and direction of operator (inward or outward).



Alternatively the swing angle can be determined more accurately with the process detailed on page 35.




FIGURE 28. ESTIMATE SWING ANGLE

2. Determine a suitable height for the wall bracket.



The gate bracket must fit to a sturdy point on the gate.
Consider using the optional Gate Adaptor Kit.



Take care to make sure the operator is mounted level.




FIGURE 29. GATE HEIGHT

3. Determine where to put the bracket according to A and B values in the tables on pages 30, 31, 33 and 34.




FIGURE 30. BRACKET POSITION




FIGURE 31. BRACKET POSITION

- Secure the bracket to the wall with the most appropriate means.



It is critical that the wall bracket is securely mounted.



See page 15 for site considerations.




FIGURE 32

Determine the Gate Bracket Position



Start with the operator fully retracted.

Turn out the actuator tube one or two turns.

- Fit the gate bracket to the operator.




FIGURE 33

6. Fit the motor end of the operator to the wall bracket.




FIGURE 34

7. Open the gate fully and temporarily clamp the gate bracket to the gate.



The gate bracket must fit to a sturdy point on the gate.

Consider using the optional Gate Adaptor Kit. See page 13.




FIGURE 35

8. Unlock the operator and swing the gate into the closed position.
9. Remove the pin and the operator from the bracket, check that there is at least one or two turns of the actuator before it is fully extended.




FIGURE 36



If it becomes obvious that the operator does not have enough stroke, reduce either the A or B distances by moving the wall bracket. A and B are illustrated in Figure 30 in page 24.



Be sure not to make the A and B values less than allowed for in the installation tables on page 30 and 31.




FIGURE 37

In general:

- Large B distances give good security and good closing push force
- Small A and small B will increase the speed

Fasten Gate Bracket to Gate

10. Secure the gate bracket using the most appropriate means.



It is critical that the gate bracket is securely mounted.



See page 16 for site considerations.




FIGURE 38

11. Fit the operator, wall bracket pins and snap



As an additional security item, add a padlock, as well as the snap ring.




FIGURE 39

12. Fit the operator, additional security gate bracket pins and snap rings.



As additional security to the snap ring, fit a padlock and the optional padlock shield.




FIGURE 40

Adjust Origin Clamp

13. Unlock the operator and open the gate to the desired fully open position.
14. Slide the origin clamp along the actuator tube, right up to the operator. Secure in place with an Allen key and tighten properly.




FIGURE 41

15. Attach warning decals to the gate as shown.



FIGURE 42

Inward Swing Gate Setup




FIGURE 43



For gates opening 90° or less as A and B are shown.



For best security (but slower operation) install with large B value.

For fast operation (but less security) install with small A and small B values.



Ensure that the gate does not exceed the gate mass specifications on page 11.



For gates opening more than 90° as A and B are shown.




FIGURE 44. OPENING 90° OR LESS




FIGURE 45. OPENING MORE THAN 90°

For V400 (400mm operator)




FIGURE 46

Recommended positions

(Only for a 2.5 metre gate or shorter)

Gate swing angle	A Value	B Value
90° or less	160	200
100°	120	180
110°	120	130
120°	110	110




FIGURE 47

Alternative positions

Gate swing angle	A+B should not exceed	A and B must each be greater					
		Up to 1.5 metres	Up to 2 metres	Up to 2.5 metres	Up to 3 metres	Up to 3.5 metres	Up to 4 metres
60° - 90° or less	380mm	110mm	110mm	110mm	120mm	140mm	160mm
100°	310mm	110mm	110mm	110mm	120mm	140mm	160mm
110°	265mm	110mm	110mm	110mm	Not recommended		
120°	220mm						



110mm for A or B would ensure a 10mm clearance between the operator and gate if the gate is 50mm thick.

For V500 (500mm operator)




FIGURE 48

Recommended positions

(Only for a 2.5 metre gate or shorter)

Gate swing angle	A Value	B Value
90° or less	205	250
100°	165	215
110°	144	180
120°	115	150




FIGURE 49

Alternative positions

Gate swing angle	A+B should not exceed	A and B must each be greater					
		Up to 1.5 metres	Up to 2 metres	Up to 2.5 metres	Up to 3 metres	Up to 3.5 metres	Up to 4 metres
60° - 90° or less	460mm	110mm	110mm	110mm	120mm	140mm	160mm
100°	400mm	110mm	110mm	110mm	120mm	140mm	160mm
110°	340mm	110mm	110mm	110mm	Not recommended		
120°	285mm						



110mm for A or B would ensure a 10mm clearance between the operator and gate if the gate is 50mm thick.

Outward Swing Gate Setup



For gates opening 90° or less as A and B are as shown.



For best security (but slower operation) install with large B value

For fast operation (but less security) install with small A and small B values



Ensure that the gate does not exceed the gate mass specifications on page 11.



For gates opening more than 90° as A and B are shown.




FIGURE 50. OPENING 90° OR LESS





FIGURE 51



Outward opening swing gates must have physical endstops fitted in the open position.

FIGURE 52. OPENING MORE THAN 90°

For V400 (400mm operator) outward




FIGURE 53

Recommended positions

(Only for a 2.5 metre gate or shorter)

Gate swing angle	A Value	B Value
90° or less	173	191
100°	145	160
110°	120	130
120°	106	114




FIGURE 54

Alternative positions

Gate swing angle	A+B should not exceed	A and B must each be greater					
		Up to 1.5 metres	Up to 2 metres	Up to 2.5 metres	Up to 3 metres	Up to 3.5 metres	Up to 4 metres
60° - 90° or less	365mm	110mm	110mm	110mm	120mm	140mm	160mm
100°	310mm	110mm	110mm	110mm	120mm	140mm	160mm
110°	265mm	110mm	110mm	110mm	Not recommended		
120°	220mm						



110mm for A or B would ensure a 10mm clearance between the operator and gate if the gate is 50mm thick.

For V500 (500mm operator) outward




FIGURE 55

Recommended positions

(Only for a 2.5 metre gate or shorter)

Gate swing angle	A Value	B Value
90° or less	222	246
100°	185	205
110°	155	170
120°	128	139




FIGURE 56

Alternative positions

Gate swing angle	A+B should not exceed	A and B must each be greater					
		Up to 1.5 metres	Up to 2 metres	Up to 2.5 metres	Up to 3 metres	Up to 3.5 metres	Up to 4 metres
60° - 90° or less	455mm	110mm	110mm	110mm	120mm	140mm	160mm
100°	390mm	110mm	110mm	110mm	120mm	140mm	160mm
110°	330mm	110mm	110mm	110mm	Not recommended		
120°	275mm						



110mm for A or B would ensure a 10mm clearance between the operator and gate if the gate is 50mm thick.

11. Determine Gate Swing Angle

Use this procedure to accurately determine the gate opening angle:

Step 1

1. Close the gate and measure a distance of one metre from the centreline of the gate hinge.
2. Make a mark on the ground.



FIGURE 57

Step 2

3. Open the gate and measure along the gate a distance of one metre from the centreline of the gate hinge.
4. Make a mark on the ground.
5. Measure the distance on the ground between the two marks (Z).
6. Using this Z value, read off the gate opening angle from the table below.




FIGURE 58

Step 3

Gate opening angle

Value Z from	To	Use gate swing angle of
1 000mm	1 075mm	60°
1 075mm	1 218mm	70°
1 218mm	1 351mm	80°
1 351mm	1 475mm	90°
1 474mm	1 587mm	100°
1 587mm	1 687mm	110°
1 687mm	1 732mm	120°

12. Allowable Wind Load

Wind speeds for which operator will still operate the gate (for V400 or V500 operators)

For a 25% covered gate: (palisades, etc.) x 1.8 metre high						
Value of A or B dimension once installed *	Gate lengths:					
	Up to 1.5 metres	Up to 2 metres	Up to 2.5 metres	Up to 3 metres[☆]	Up to 3.5 metres[☆]	Up to 4 metres[☆]
100mm	94km/h	66km/h	48km/h	44km/h	41km/h	37km/h
140mm	119km/h	85km/h	65km/h	57km/h	51km/h	46km/h
180mm	138km/h	101km/h	78km/h	67km/h	60km/h	53km/h
220mm	156km/h	114km/h	89km/h	76km/h	67km/h	60km/h
260mm	171km/h	126km/h	99km/h	84km/h	74km/h	65km/h
300mm	186km/h	137km/h	108km/h	91km/h	80km/h	71km/h
340mm	199km/h	147km/h	116km/h	98km/h	86km/h	76km/h

* See page 24 or 25 for installation details

☆ An electric lock must be fitted

Wind speeds for which operator will still operate the gate (for V400 or V500 operators)

For a 100% covered gate: (Fully clad gates, etc.) x 1.8 metre high						
Value of A or B dimension once installed *	Gate lengths:					
	Up to 1.5 metres	Up to 2 metres	Up to 2.5 metres	Up to 3 metres[☆]	Up to 3.5 metres[☆]	Up to 4 metres[☆]
100mm	47km/h	33km/h	24km/h	22km/h	47km/h	19km/h
140mm	59km/h	43km/h	32km/h	28km/h	59km/h	23km/h
180mm	69km/h	50km/h	39km/h	34km/h	69km/h	27km/h
220mm	78km/h	57km/h	44km/h	38km/h	78km/h	30km/h
260mm	86km/h	63km/h	49km/h	42km/h	86km/h	33km/h
300mm	93km/h	68km/h	54km/h	46km/h	93km/h	35km/h
340mm	100km/h	74km/h	58km/h	49km/h	100km/h	38km/h

* See page 24 or 25 for installation details

☆ An electric lock must be fitted

13. Electrical Setup

1. Always check that the circuit breaker in the electrical panel is in the OFF position, and that all high-voltage circuits (more than 42.4V) are completely isolated from the mains supply before doing any work.
2. Ensure that all low-voltage systems (less than 42.4V) are suitably protected from damage, by disconnecting all sources of power such as chargers and batteries before doing any work.
3. All electrical work must be carried out according to the requirements of all applicable local electrical codes. (It is recommended that a licensed electrical contractor perform such work)



Secure Control Box to Wall

1. Secure the Control Box to the wall using the most appropriate means.

Be sure to position the Control Box so as not to cause any hazards during and after the installation



Preferably mount the Control Box:

- out of direct sunlight
- at a comfortable working height
- away from garden sprinklers, etc.
- to allow easy access even when the gate is open




FIGURE 59

Connect all Wiring

2. Connect all the cables as required to the control card. See pages 40, 41, 42 and 43.
3. When wiring each operator back to the controller housing, it is recommended to mount a small junction box adjacent to each operator. Terminate the cable provided on the operator into this junction box and then route a new cable from the junction box to the controller housing.




FIGURE 60

It is **essential** that the installer tie off the harness in such a way so as to **allow for a 350mm loop** between the cable exit at the back of the operator and either the mounting bracket or junction box, to minimise the flexing of the harness. If a sharp bend is introduced to the cable harness, or a loop that is less than 350mm in diameter, the resulting




FIGURE 61



- Select the 'Limits' menu by pressing the enter button (■). Follow the onscreen instructions to complete the setup procedure.
- When prompted to select the operator, always ensure that **'VECTOR'** is selected.




FIGURE 65

14. Wiring Diagram for Closing Safety Beams




FIGURE 66. WIRING OF SAFETY DEVICE

15. Wiring Diagram for Opening Safety Beams




FIGURE 67. WIRING OF SAFETY DEVICE

16. Wiring Diagram for External Radio Receiver and Loop Detector




FIGURE 68. WIRING OF OTHER INPUTS

17. Wiring Diagram for Other Inputs




FIGURE 69. WIRING OF OTHER INPUTS

18. Wiring Diagram for Master Motor (MTRM)




FIGURE 70. WIRING OF THE MASTER MOTOR

19. Wiring Diagram for Slave Motor (MTRS)




FIGURE 71. WIRING OF THE SLAVE MOTOR

20. Charger and Pillar Light Connections




FIGURE 72. CHARGER AND PILLAR LIGHT CONNECTIONS

Fuse protection

The following protection fuses are provided on the system:

Item	Type	Rating
Main controller		
Motor Circuit - fuse per channel	Automotive Fuse (25 x 7)	15A
Light circuit	5 x 20mm	3A Fast Blow
Auxiliary supply	Electronic fuse** - not replaceable	3A
Charger		
Mains Input	5 x 20mm	250mA Fast Blow

** To reset: Power off controller for at least one minute and re-apply power

21. Solar Panel Wiring




FIGURE 73. WIRING DIAGRAM FOR A SOLAR PANEL TO GATE MOTOR

22. Setting up Additional Features

Figure 69 provides the full menu of features that can be set up on the system. An explanation of each feature is provided in the section 'Controller Features'.

When setting up the **VECTOR2** system via the LCD display, all the steps that have to be followed are clearly provided via the display. It is only necessary to note the following:

1. To get into Setup Mode, press the (■) button for three seconds and follow the instructions provided from there.
2. The buttons provided on the controller for navigating the system are not marked because at each step during the Setup, the function given to each button is provided on the display.




FIGURE 74. VIEW OF CONTROLLER

3. When not in Setup Mode, i.e. Normal Mode, the (●) button is used as a test button for operating the system. The up/down buttons are not used unless the diagnostic screens have been selected to appear in Normal Mode, in which case these buttons allow switching from one screen to the next.



For each feature a Factory Default setting has been programmed into the controller. Referred to as an Operating Standard, these defaults have been determined to suit the requirements of the specific region where the installation is being carried out. It is only necessary to change a feature where the default does not suit the installation. When selecting any feature in the menu, details of the current setting stored in the controller are displayed.

Refer to Table 1 on page 63 for the Schedule of Factory Defaults for each feature.

23. Menu Navigation Map



1. Setting limits



1.1. Setup wizard



2. Safety

- 2.1. MTRM Collision Force
 - 2.1.1. MTRM Opening Collision Force
 - 2.1.2. MTRM Closing Collision Force

- 2.2. MTRS Collision Force
 - 2.2.1. MTRS Opening Collision Force
 - 2.2.2. MTRS Closing Collision Force

- 2.3. Collision Count



3. Autoclose

- 3.1. Autoclose Status
- 3.2. Autoclose Timer
- 3.3. Autoclose Override
- 3.4. Autoclose Advanced options
 - 3.4.1. Autoclose fully open
 - 3.4.2. Autoclose partly open
 - 3.4.3. Autoclose partly closed



4. Modes of Operation

- 4.1. Operating Mode
 - 4.1.1. Standard Mode
 - 4.1.2. Condominium Mode
 - 4.1.3. Reversing Mode



5. Run profile

- 5.1. Positive Close
 - 5.1.1. Positive Close Status
 - 5.1.2. Positive Close Type
 - 5.1.2.1. Short Stop
 - 5.1.2.2. MTRM Only
 - 5.1.2.3. MTRS Only
 - 5.1.2.4. MTRM and MTRS
 - 5.1.3. Positive Close Short Stop Value
 - 5.1.4. Positive Close Push Force



5.2 Leaf delay

2.1.1. Leaf Delay Status

2.2.1. Leaf Delay Value

5.2. Pre-open delay

5.3. Pre-close delay

5.4. Opening speed

5.5. Closing speed

5.6. Ramp-up distance

5.7. Ramp-down distance

5.8. TRG stop distance

5.9. IRB stop distance

5.10. Crawl distance

5.11. Torque limit



6. IR Beams

6.1. PIRAC control

6.1.1. PIRAC status

6.1.2. Stop on open

6.1.2.1. Stop on open status

6.1.2.2. Stopping distance

6.2. IR beam test

6.2.1. Status

6.2.2. Test beam

6.3. IRBO=IRBC on closing

6.4. IR beam Alarms

6.4.1. Ambush Alarm

6.4.1.1. Ambush Alarm status

6.4.1.2. Broken IRB time

6.4.2. Break-in Alarm status

6.4.3. Alarm output



7. Pedestrian

7.1. Pedestrian Open Position

7.2. Pedestrian Autoclose time

7.3. Pedestrian pre-open delay

7.4. Pedestrian pre-close delay



8. Gate lock

8.1. Lock Enabled Status

8.2. Lock Type

8.3. Release Time

8.4. Pre-Release Time

8.5. Lock Location

8.6. Lock Drive (AC/DC)



9. Courtesy Light

- 9.1. Courtesy Light timer
- 9.2. Light Profile
 - 9.2.1. Courtesy Light
 - 9.2.2. Pre-flash A
 - 9.2.3. Pre-flash B
 - 9.2.4. Pre-flash C



10. General settings

- 10.1. Operator
 - 10.1.1. **VECTOR**
 - 10.1.2. VERT-X
 - 10.1.3. VANTAGE
- 10.2. Operating Profile
 - 10.2.1. ZA
 - 10.2.2. CE
 - 10.2.3. UL325
- 10.3. Reset Options
 - 10.3.1. Factory Default
 - 10.3.2. Delete all remotes
 - 10.3.3. Reset all
- 10.4. Diagnostic screen
 - 10.4.1. Turn Diagnostics on
 - 10.4.2. Turn Diagnostics off
- 10.5. Round test button
 - 10.5.1. Round test button on
 - 10.5.2. Round test button off



11. Remote Controls



Press button of valid remote control (*if menu locked*)

- 11.1. Add remotes
- 11.2. Delete remotes
 - 11.2.1. Delete by ID
 - 11.2.2. Delete button
 - 11.2.3. Delete by button
 - 11.2.4. Delete all remotes
- 11.3. Edit remote button
- 11.4. Autolearn remotes
- 11.5. Tx menu locked
- 11.6. Onboard receiver enable/disable

24. Controller Features



Menu 2 - Safety (Collision Force)

1. Collision Force

If the gate is obstructed, the internal collision circuitry will activate.

The response of the system to a collision will vary, depending on the Profile selected (Operating Standard, e.g. ZA). Responses can vary from the gate stopping, to the gate reversing. The Collision Force can be set from minimum to maximum in five discrete steps.

A sixth step will disable collision sensing entirely, allowing maximum force to be achieved. Under this condition, the motor will continue running until it stalls, at which point a collision will be detected.



This level should only be used if additional safety measures are taken (e.g. Infrared Safety Beams, etc.).

Collision Force can be set independently per direction of travel.

2. Collision Count

A counter monitors the number of collisions that the gate experiences before it reaches the fully closed position. If the value exceeds the value set in the Multiple Collision Counter the controller shuts down until the next valid trigger is received. As an indication, the status LED will flash four times every two seconds. The Multiple Collision fault indication will continue to flash indefinitely or until a valid trigger has been received.



Menu 3 - Autoclose

1. Autoclose status

When turned on, the **Autoclose** feature has the function of automatically closing the gate after a preset **Autoclose** time. The **Autoclose** feature is automatically turned on when the controller is set for **Condominium Mode**.

2. Autoclose time

The **Autoclose** time can be set anywhere from 1 to 255 seconds.

3. Autoclose Override

It is possible for the user to temporarily turn off **Autoclose** when the Mode of Operation is **Standard** or **Reversing**. To activate **Autoclose Override**, the Trg input must be activated and maintained for a period longer than the time set for the **Autoclose Override Time**.

The gate response will be to start opening on the Trg trigger, and then to stop as soon as the **Autoclose Override** feature is activated. On clearing of the Trg input, the gate will continue opening until fully open. The **Autoclose** feature is now off and the gate will remain open indefinitely.

The next signal received on Trg will clear the **Autoclose Override** feature, close the gate, and set the **Autoclose** feature back to normal.

4. Autoclose Advanced Options

The conditions under which the gate will automatically close can be set within the **Advanced Autoclose** options menu:

- 4.1. **Autoclose on open** - automatically close the gate if it has reached the fully open position
- 4.2. **Autoclose on partly open** - automatically close the gate if it is stopped while opening, but before reaching the fully opened position.
- 4.3. **Autoclose on partly closed** - automatically close the gate if it is stopped while closing, but before reaching the fully closed position.



More than one advanced option can be selected.



Menu 4 - Modes of Operation

It is possible to select the following Modes of Operation: **Standard**, **Condominium**, and **Reversing Mode**.

All modes are triggered by closing a normally-open contact between the Trg input terminal and the Com terminal.

1. Standard Mode

When stationary, a trigger impulse on Trg will cause the gate to either open or close. On a moving gate, a trigger impulse on Trg will stop the gate. The next impulse on Trg will cause the gate to reverse its direction of travel, i.e. the action is **start-stop-reverse**.

2. Condominium Mode

A trigger impulse on Trg will open the gate under all conditions. If it were closing, it would stop and reverse to open. In this Mode of Operation, the only way to close the gate is with the **Autoclose** feature, which is automatically activated when **Condominium Mode** is selected.

3. Reversing Mode

A trigger impulse on Trg will reverse the direction of a moving gate. If it were closing, it would stop and immediately begin opening. If it were opening, it would stop and immediately begin closing.



Menu 5 - Run Profile

1. Positive Close Mode (PCM)

Setting **Positive Close Mode** to ON will allow the gate to drive up hard to the closed endstop without causing the collision circuitry to operate.

This feature operates only during the last few millimetres of gate travel in Closing Mode.

2. Positive close type

PCM can be applied to one of the following:

- Short Stop (further explanation follows)
- Master Motor (MTRM)
- Slave Motor (MTRS)
- Both Master and Slave Motors

3. Short Stop

PCM applied to one gate is ideal for securely locking two gates to each other without having to fit endstops. Typically, a 'mechanical' lip is fitted to one gate which will push up against the other gate and via PCM keep pushing until the gates are mechanically locked. To ensure that the gates do not close past their desired end point, the Slave Gate against which the Master Gate with the mechanical lip pushes, can be preset to stop slightly short of its closed position. This is referred to as the 'Short Stop' distance. If the 'Short Stop' distance is correctly set, the Master Gate will engage with the Slave Gate sufficiently before the closed position and via the PCM, push the two gates into the fully closed position, but not past it.

4. Short Stop value

The Short Stop distance can be set between 1mm and 40mm of piston stroke.

5. PCM push force

The amount of force applied by the actuator when in PCM can be set as a value from 1 to 15.

6. Leaf Delay

Leaf Delay is used in cases where one gate leaf must move before the other. The most common need for this arises when a mechanical 'lip' is fitted to one of the gates. In a double leaf installation, a Leaf Delay can be set whereby the MTRM Motor will open before the MTRS Motor and the MTRS Motor will close before the MTRM Motor.

7. Leaf Delay value

The Leaf Delay is based on piston position, and can be adjusted from 3mm to 250mm of piston travel.

8. Pre-open Delay

Allows a delay between a valid trigger signal being received and the gate commencing movement in the opening direction. A Warning Light can be set to activate during this delay. (Refer to Pre-flash Modes of the feature 'Pillar Light', for more details.)

This setting applies to both motors.




FIGURE 75




FIGURE 76




FIGURE 77




FIGURE 78

9. Pre-close Delay

Allows a delay between a valid trigger signal being received and the gate commencing movement in the closing direction. The delay will also occur if the gate is set to close automatically. A Warning Light can be set to activate during this delay. (Refer to Pre-flash Modes of the feature 'Pillar Light', for more details). This setting applies to both operators.

10. Opening Speed

Sets the maximum piston opening speed in millimeters per second. This setting applies to both operators.

11. Closing Speed

Sets the maximum piston closing speed in millimeters per second. This setting applies to both operators.

12. Ramp-up Distance

Sets the Ramp-up Distance in millimeters of travel of the piston when starting. This setting applies to both operators.

13. Ramp-down Distance

Sets the Ramp-down Distance in millimeters of travel of the piston when stopping. This setting applies to both operators.

14. Crawl Distance

Sets the final Crawl Distance in millimeters of travel of the piston when reaching an endpoint. This setting applies to both operators.

15. Push Force Limit

Sets the maximum push force delivered by the operators. The maximum setting is a value of 15 and the minimum is four. This is useful in cases where limited push force is required. This setting applies to both operators.

I5 Menu 6 - IR beams

In a swing gate installation, in order to provide protection to a person or vehicle moving through the entrance, it is necessary to have two sets of Safety Beams, one across the driveway where the gates are closed and another where the gates are open. Both sets of Safety Beams must be set as Closing Safety Beams, preventing the gate from closing and stopping the gates if they have started to close.

However, across the line of the driveway up to where the gates open, it is also recommended to have another set of Safety Beams to prevent the gate from opening if they are closed and stop if they are opening.




FIGURE 79

Two independent normally-closed inputs are provided for Opening and Closing Safety Beams.

An interrupted closing beam will prevent the gates from closing and stop and reverse the gates back to the open position if already opening. Vice-versa for an opening beam.

Additional beam functionality is provided:

1. PIRAC Autoclose

The **Passive-Infrared Autoclose** feature allows the gate to close automatically, as soon as a vehicle or pedestrian has passed through the closing beam. This security feature ensures that the gate stays open for the minimum amount of time possible.

If the **Autoclose** feature has been enabled, the system will react in the following way:

- When the gate is triggered to open and nothing moves through or interrupts the closing beam, the gate will open fully and stay open for the period of time determined by the **Autoclose TIMER**
- However, if the closing beam is interrupted at any stage, while the gate is opening or open, the gate will close immediately after the closing beam is cleared



If the **Autoclose** feature has **not** been enabled then the gate will remain open indefinitely. To close the gate the closing beam must be interrupted or the trigger button must be pressed.

2. Safe Output Status

Automatically tests the Safety Beams before each gate cycle. (E.g. as required by CE and UL325)



In order for this feature to work, the power supply negative of the beam transmitter must be wired to the Safe Com terminal of the controller.

- The time taken for the gate to open again after it has come to a stop is approximately three seconds

Example:

- **Autoclose Override** time set to five seconds: Total time to temporarily disable the PIRAC feature is approximately eight seconds (5s + 3s = 8 seconds)




FIGURE 80

3. IR Beam Test (only compatible with i5 Safety Beams; not compatible with wireless Safety Beams).

Automatically tests the Safety Beams before each gate cycle. (E.g. as required by CE.)

In order for this feature to work, the power supply negative of the beam transmitter must be wired to the Safe Com terminal of the controller.

4. IRBO=IRBC

Configures the opening beam to act as a closing beam while the gates are closing. This allows one set of Safety Beams to be used across the line of the driveway up to where the gates open.

5. IR Beam Alarms

While the gate is fully closed, this feature allows the following alarms:

A. Ambush Alarm

Activates an alarm if either the Opening or Closing Beams have been continuously interrupted for a pre-defined time. The alarm will remain activated while the beams are interrupted. For example, if a would-be intruder covers the Safety Beams so that when the gate is opened, the gate will stay open, the system will detect this beam override taking place and set off an alarm.




FIGURE 81

B. IR Beam Broken Time

The time that the Beams must be interrupted before the alarm is activated.

C. Break-in Alarm

Activates an alarm if the Closing Beam on the outside of the property is interrupted. The alarm remains activated while the Beams are broken, and for a period of 30 seconds thereafter. This time is fixed.




FIGURE 82



If this alarm is used, it is recommended that TWO parallel Closing Beams are used to reduce the chance of false triggering.

D. Alarm output

The system can be configured to operate one of the following outputs provided on the controller:

- **Onboard buzzer** - emits a continuous tone
- **Pillar / Courtesy Light contact** (potential-free normally-open contact, fuse-protected - 5A)
- **Aux IO** (this is an open collector drive, maximum current draw 3A, not fuse-protected)
- **Safety beam common** (this is an open collector drive, maximum current draw 3A, not fuse-protected)
- **Status LED output** (operate up to three LEDs in parallel or interface with the CP78 MULTI-LED driver card)



Menu 7 - Pedestrian Opening

This feature is associated with the PED input on the controller. When activating this input, the system will open the gate to the Pedestrian Open position, and then automatically close after the Pedestrian Autoclose time lapses. If the PED connection to Com is maintained, then the gate will remain open, and when the connection is broken, it will close after the Pedestrian Autoclose time has expired.

The time taken for the gate to open to pedestrian is dependent on the pedestrian Pre-open Delay and the time required for the gate to close from the pedestrian position is dependent on the Pedestrian Pre-close Delay.

1. Pedestrian Open Position

Sets the maximum opening of the pedestrian gate in metres, in one centimetre steps.

2. Pedestrian Autoclose Time

Sets the Autoclose time in seconds after a Pedestrian Opening. This time can be set from zero seconds to four minutes in one second steps.

3. Pedestrian Pre-open Delay

Sets the time delay between the pedestrian input being activated, and the gate actually opening. This enhances safety in cases where the pedestrian has to reach through the gate in order to activate the pedestrian input. A Warning Light* would typically be active during this delay. This delay can be set from zero seconds to four minutes in one second steps.

4. Pedestrian Pre-close Delay

Sets the time delay between the Pedestrian Autoclose timer expiring, and the gate actually closing. A Warning Light* would typically be active during this delay. This delay can be set from zero seconds to four minutes in one second steps.



* The Warning Light is any light wired to the Pillar Light contacts, as described in Menu 9.



Menu 8 - Gate Lock

A solenoid strike lock or magnetic lock can be connected to the control card, allowing the gate to be locked when closed, open or both.

1. Lock enable status

Turns the lock functionality on or off.

2. Lock type

Allows selection of either a solenoid strike lock, or a magnetic lock. A solenoid strike unlocks when power is applied, while a magnetic lock unlocks when power is removed.

3. Release time

Sets the Time-period (in seconds) for which the lock remains released after the gate has started moving.

A. Pre-Release time

Sets the Time-period (in 0.1 second increments) for which the lock releases BEFORE the gate has started moving. This is useful in cases where premature gate movement prevents the lock from releasing.

B. Lock location

Specifies whether the gate is locked while closed, open or both.

C. Lock drive

Specifies if the lock is to be powered by an AC or DC voltage. Selecting AC will power the lock with a 50Hz square wave.



Menu 9 - Courtesy/Pillar Light

This feature is associated with the **Light** connections on the controller. Refer to Section 16 of the manual for details on how to connect a Pillar or security Light to the controller.

The Pillar Light circuit has multiple functions:

- It operates as a Courtesy Light and switches on for a selectable time period every time the gate is activated
- The Courtesy Light can also be turned on for the same time period by momentarily connecting the Aux 12V terminal to the Com terminal via a pushbutton
- The Courtesy Light can also be turned on permanently by connecting the Aux 12V terminal to the Com terminal via a pushbutton, for three seconds. A short pulse thereafter will switch the lights off. The status LED will flash once every two seconds to indicate that the Courtesy Light is on permanently. The abovementioned facility can also be achieved via a remote learned to the system and mapped to the Courtesy Light function from within the remotes menu



The gate will not open when using the **Aux 12V** trigger input.

- When the PED input is triggered, the Courtesy Light flashes for an adjustable pre-flash time (1 to 255 seconds), before the pedestrian gate opens

1. Courtesy Light time

The time that the Courtesy Light will remain activated can be set from four seconds to ten hours in one second increments.

2. Light profile

The Courtesy Light can be selected to operate according to one of the following:

A. Courtesy Light as explained earlier

B. Pre-flashing Mode

- If Pre-flashing Mode A, B or C is selected, the behaviour of the Courtesy Light will be as follows:
 - **Mode A** will turn on the Courtesy Light only while the gate is moving
 - **Mode B** will flash the Courtesy Light during the Pre-opening and Pre-closing Delays, as well as while the gate is moving
 - **Mode C** will turn on the Courtesy Light during the Pre-opening and Pre-closing Delays, as well as while the gate is moving
- In these Pre-flashing Modes, the timed Courtesy Light functionality is not available



Menu 10 - General Features

1. Operator

This menu item allows the user to set the type of **V-Series** operator currently being used with the controller. Always ensure that **VECTOR** is selected.

When not in Setup Mode, i.e. Normal Mode, the currently-enabled operator will be displayed in the bottom left-hand corner of the LCD screen, with VC indicating **VECTOR**.

2. Operating Standard

Regional Operating Standards can be set. Applying this setting will automatically configure the controller settings to conform to the specific region's standard. (E.g. UL325 or CE.)

3. Reset Options

The controller settings can be reset through the Reset Options menu. Various reset options are available:

A. Factory Defaults - All settings will be restored to the default values dictated by the Operating Standard/Profile that is currently selected. All remote controls and gate limits will not be affected.

B. Delete All Remotes - Delete all the remotes stored in the system; no settings affected.

C. Reset All - Clears and defaults the system completely. The unit will be reset to the Factory Default settings in addition to clearing all remotes and time-periods.

4. Diagnostic Screen

Allows a diagnostic screen to be displayed. This can be useful when troubleshooting, but requires some technical knowledge.

5. Round Test Button

Allows the round test button on the controller to be disabled, in cases where higher security is required.



Menu 11 - Remote Controls

The controller is capable of learning up to 64 CENTURION code-hopping remote controls. Each remote control can have up to four buttons. Each remote control learned into the system is assigned a unique remote control ID.



- It is possible to artificially increase the number of buttons of a multi-button remote control by using a two-button combination
- One of the buttons is used as a **Shift Button** to allow the other buttons to be used again in combination with this button. In other words, the user will press and hold the Shift Button, before pressing one of the other buttons to create a **new** button
- The Shift Button cannot be used as a button on its own, it must always be used in combination with the other buttons

Benefits of the Shift Button system:



- Use of the **Shift Button system** allows a three-button remote control to gain an extra button and operate four functions and likewise a four-button remote control gains two extra buttons and can operate six functions
- Another benefit of using the **Shift Button system** is that **it requires both hands to operate the two-button combination**. This prevents the user from accidentally enabling sensitive functions such as Holiday Lockout on the controller
- Each remote control learned into the system is assigned a unique remote control ID

1. Press Valid Button

If the **Remote Controls Menu** has been locked as discussed later, only by pressing a button of a remote control learned into the system, can the **Remote Controls Menu** be accessed.

2. Add Remote

Any button can be set to control the Trigger, Pedestrian, Free-exit, Holiday Lockout or Courtesy Light Control (Aux) inputs. When adding remote controls, it is recommended that a record be kept of the ID number allocated by the system to each respective remote control and the person to whom the remote control is given. This is necessary should selective deletion be required at a later stage.

3. Delete Remote

Remote controls can be deleted at any stage according to one of the following methods:

A. Delete Remote by ID

Each remote control can be deleted individually according to its unique ID. To facilitate this, a record of the ID and the person to whom the ID has been assigned must have been made at the time of learning the remote control into the system. The remote control is not required for this operation.

B. Delete Remote Button

The operation of a button of a particular remote control can be cleared. For example, it allows the Holiday Lockout function set on one remote button of a remote control to be cleared, without affecting the other operations that the same remote control performs. The remote control is required for this operation.

C. Delete Remote by Button

Use this procedure to remove the remote control from the system.

All button functionality will be removed. The remote control is required for this operation.

D. Delete All Remotes

Clears the entire memory. All remote controls will be removed.

4. Edit Remote Button

Change the function on one button to perform another function. For example, button one's function is to open the gate completely. To change this, use **edit remote button**, select PED, and button one of the same remote will now only open the gate to the pedestrian setting.

5. Remote Control Menu locked

Allows the **Remote Controls Menu** to be locked, preventing the unauthorised addition of new remote controls to the system. Once enabled, the **Remote Controls Menu** can only be accessed by pressing a valid remote control button.

25. Factory Defaults Schedule

South African Standard Profile - ZA

Parameter Description	Unit	Minimum	Default	Maximum
Autoclose Enabled	Yes/No		No	
Autoclose from Fully Open	Yes/No		Yes	
Autoclose from Partly Open	Yes/No		Yes	
Autoclose from Partly Closed	Yes/No		No	
Autoclose Time	Minutes/seconds	00:00*	0:15	04:00*
Autoclose Override Time	Seconds	2*	3	15*
Mode of Operation	S, R, C†		Standard	
Motor M Opening Force	Level	1	3	Max (6)
Motor M Closing Force	Level	1	3	Max (6)
Motor S Opening Force	Level	1	3	Max (6)
Motor S Closing Force	Level	1	3	Max (6)
Max. No. Collisions	Collisions	1	4	255
Collision Alarm Output	B, C, P, S, L‡		Buzzer	
PCM Enabled	Yes/No	No	No	Yes
PCM Type	M, S, M & S, SS☆		Master Only	
PCM Short Stop Distance	Millimeters	1	5	40
PCM Force	%(A)	1	3	15
Leaf Delay Enabled	Yes/No	No	No	Yes
Leaf Delay	Millimeters	3*	10*	250*
Opening Speed	Minutes/seconds	10	30	Max
Closing Speed	Minutes/seconds	10	30	Max
Ramp-up Distance	Millimeters	20	30	400
Ramp-down Distance	Millimeters	20	30	400
Crawl Distance	Millimeters	5	10	400
Torque Limit	Amps	4	11	15
Pre-Open Delay Time	Seconds	0	0	196
Pre-Close Delay Time	Seconds	0	0	196

* Settings are fixed across standards

† S, R, C (Modes of Operation) - Standard, Reversing, Condominium

‡ B, C, P, S, L (Collision Alarm Output) - Buzzer, Courtesy Light, Safe Common, Solenoid, LED

☆ M, S, SS (PCM Type) - Master, Slave, Short Stop

South African Standard Profile - ZA (continued)

Parameter Description	Unit	Minimum	Default	Maximum
PED Open Distance	% (Fully Open)	10	30	100
PED Autoclose Time	Seconds	0	5	240
PED Pre-Open Delay Time	Seconds	0	2	240
PED Pre-Close Delay Time	Seconds	0	0	240
Gate Lock Enabled	Yes/No		No	
Gate Lock Type	Magnetic/Striker		Striker	
Gate Lock Pre-Release Time	Seconds	0.1*	0.024.0*	24.0*
Gate Lock Release Time	Seconds	0.1*	1.0*	24.0*
Gate Lock Location	C, O, C & O *		Close Only	
Gate Lock Drive Type	AC,DC	0:00:04 *	AC	9:59:59*
Courtesy Light Time	H:mm:ss*		0:02:00	
Courtesy Light Profile	Crt, A, B, C ☆	No	Courtesy	Yes
PIRAC Enabled	Yes/No	No	No	Yes
SAF Common Enabled	Yes/No		No	
SAF Common Tests which Beams	C, O, C & O ◇	No	IRBC Only	Yes
IRBO acts as IRBC	Yes/No	No	No	Yes
IRB Ambush Alarm Enabled	Yes/No	1	Yes	225
IRB Ambush Alarm Hold-Off Time	Minutes	No	1	Yes
IRB Break-In Alarm Enabled	Yes/No		No	
IRB Alarms Output	B, C, P, S, L ☼		Buzzer	
Diagnostic Screen Enabled	Yes/No		No	
Test Pushbutton Enabled	Yes/No		Yes	
Remote Menu Locked	Yes/No		No	
IRBO Starts Wireless★	Yes/No		Yes	
IRBC Starts Wireless★	Yes/No		Yes	
LCK Starts Wireless★	Yes/No		Yes	
Operator	VC, VX, VN		VC	

* Settings are fixed across standards

☼ C, O (Gate Lock Location) - Closed, open

* H, mm, s (Courtesy Light Time) - Hours, minutes, seconds

☆ Crt, A, B, C (Courtesy Light Profile) - Courtesy, Profile A, Profile B, Profile C

◇ C, O (SAF COM tests which beams) - Closing, opening

☼ B, C, P, S, L (IR Alarms Output) - Buzzer, Courtesy Light, Safe Common, Solenoid, LED

★ Settings are not configurable via the GUI

CE Standard Profile

Parameter Description	Unit	Minimum	Default	Maximum
Autoclose Enabled	Yes/No		No	
Autoclose From Fully Open	Yes/No		Yes	
Autoclose From Partly Open	Yes/No		Yes	
Autoclose From Partly Closed	Yes/No		No	
Autoclose Time	Minutes/seconds	00:00*	00:15	04:00*
Autoclose Override Time	Seconds	2*	3	15*
Mode Of Operation	S, R, C†		Standard	
Motor M Opening Force	Level	1	3	Max (6)
Motor M Closing Force	Level	1	3	Max (6)
Motor S Opening Force	Level	1	3	Max (6)
Motor S Closing Force	Level	1	3	Max (6)
Max. No. Collisions	Collisions	1	4	255
Collision Alarm Output	B, C, P, S, L‡		Buzzer	
PCM Enabled	Yes/No	No	No	Yes
PCM Type	M, S, M & S, SS★		Master Only	
PCM Short Stop Distance	Millimeters	1	10	40
PCM Force	% (A)	1	3	15
Leaf Delay Enabled	Yes/No	No	No	Yes
Leaf Delay	Millimeters	3*	10*	250*
Opening Speed	Minutes/seconds	10	30	30
Closing Speed	Minutes/seconds	10	30	30
Ramp-up Distance	Millimeters	20	30	400
Ramp-down Distance	Millimeters	20	30	400
Crawl Distance	Millimeters	5	5	400
Torque Limit	Amps	4	11	15
Pre-Open Delay Time	Seconds	0	0	196
Pre-Close Delay Time	Seconds	0	0	196

* Settings are fixed across standards

† S, R, C (Modes of Operation) - Standard, Reversing, Condominium

‡ B, C, P, S, L (Collision Alarm Output) - Buzzer, Courtesy Light, Safe Common, Solenoid, LED

★ M, S, SS (PCM Type) - Master, Slave, Short Stop

CE Standard Profile (continued)

Parameter Description	Unit	Minimum	Default	Maximum
PED Open Distance	% (Fully Open)	10	50	100
PED Autoclose Time	Seconds	0	5	240
PED Pre-Open Delay Time	Seconds	0	2	240
PED Pre-Close Delay Time	Seconds	0	0	240
Gate Lock Enabled	Yes/No		No	
Gate Lock Type	Magnetic/Striker		Maglock	
Gate Lock Pre-Release Time	Seconds	0.0*	0.0	24.0*
Gate Lock Release Time	Seconds	0.1*	1.0	24.0*
Gate Lock Location	C, O, C & O*		Close Only	
Gate Lock Drive Type	AC, DC		DC	
Courtesy Light Time	H:mm:ss*	0:00:04*	00:02:00	9:59:59*
Courtesy Light Profile	Crt, A, B, C☆		PFA	
PIRAC Enabled	Yes/No	No	No	Yes
SAF Common Enabled	Yes/No	Yes	Yes	Yes
SAF Common Tests which Beams	C, O, C & O◇	No	IRBC Only	Yes
IRBO acts as IRBC	Yes/No	No	No	
IRB Ambush Alarm Enabled	Yes/No	1	No	Yes
IRB Ambush Alarm Hold-off Time	Minutes	No	1	255
IRB Break-In Alarm Enabled	Yes/No		No	Yes
IRB Alarms Output	B, C, P, S, L*‡		Buzzer	
Diagnostic Screen Enabled	Yes/No		No	
Test Pushbutton Enabled	Yes/No		Yes	
Remote Menu Locked	Yes/No		No	
IRBO Starts Wireless★	Yes/No		Yes	
IRBC Starts Wireless★	Yes/No		Yes	
LCK Starts Wireless★	Yes/No		Yes	
Operator	VC, VX, VN		VC	

* Settings are fixed across standards

* C, O (Gate Lock Location) - Closed, open

* H, mm, s (Courtesy Light Time) - Hours, minutes, seconds

☆ Crt, A, B, C (Courtesy Light Profile) - Courtesy, Profile A, Profile B, Profile C

◇ C, O (SAF COM tests which beams) - Closing, opening

* B, C, P, S, L (IR Alarms Output) - Buzzer, Courtesy Light, Safe Common, Solenoid, LED

★ Settings are not configurable via the GUI

UL325 Standard Profile

Parameter Description	Unit	Minimum	Default	Maximum
Autoclose Enabled	Yes/No		No	
Autoclose From Fully Open	Yes/No		Yes	
Autoclose From Partly Open	Yes/No		Yes	
Autoclose From Partly Closed	Yes/No		No	
Autoclose Time	Minutes/seconds	00:00*	00:15	04:00*
Autoclose Override Time	Seconds	2*	3	15*
Mode Of Operation	S, R, C †		Standard	
Motor M Opening Force	Level	1	3	Max (6)
Motor M Closing Force	Level	1	3	Max (6)
Motor S Opening Force	Level	1	3	Max (6)
Motor S Closing Force	Level	1	3	Max (6)
Max. No. Collisions	Collisions	1	2	2
Collision Alarm Output	B, C, P, S, L ‡		Buzzer	
PCM Enabled	Yes/No	No	No	Yes
PCM Type	M, S, M & S, SS ☆		Master Only	
PCM Stop Short Distance	Millimeters	1	10	40
PCM Force	% (A)	1	3	15
Leaf Delay Enabled	Yes/No	No	No	Yes
Leaf Delay	Millimeters	3*	10*	250*
Opening Speed	Minutes/seconds	10	30	30
Closing Speed	Minutes/seconds	10	30	30
Ramp-up Distance	Minutes/seconds	20	30	400
Ramp-down Distance	Minutes/seconds	20	30	400
Crawl Distance	Millimeters	5	5	400
Torque Limit	Amps	4	11	15
Pre-Open Delay Time	Seconds	0	0	196
Pre-Close Delay Time	Seconds	0	0	196

* Settings are fixed across standards

† S, R, C (Modes of Operation) - Standard, Reversing, Condominium

‡ B, C, P, S, L (Collision Alarm Output) - Buzzer, Courtesy Light, Safe Common, Solenoid, LED

☆ M, S, SS (PCM Type) - Master, Slave, Short Stop

UL325 Standard Profile (continued)

Parameter Description	Unit	Minimum	Default	Maximum
PED Open Distance	% (Fully Open)	10	50	100
PED Autoclose Time	Seconds	0	5	240
PED Pre-Open Delay Time	Seconds	0	2	240
PED Pre-Close Delay Time	Seconds	0	0	240
Gate Lock Enabled	Yes/No		No	
Gate Lock Type	Magnetic/Striker		Maglock	
Gate Lock Pre-Release Time	Seconds	0.0*	0.0	24.0*
Gate Lock Release Time	Seconds	0.1*	1.0	24.0*
Gate Lock Location	C, O, C & O*		Close Only	
Gate Lock Drive Type	AC, DC		DC	
Courtesy Light Time	H:mm:ss*	0:00:04*	0:02:00	9:59:59*
Courtesy Light Profile	Crt, A, B, C☆		Courtesy	
PIRAC Enabled	Yes/No	No	No	Yes
SAF Common Enabled	Yes/No	No	No	Yes
SAF Common Tests which Beams	C, O, C & O◇	No	IRBC Only	Yes
IRBO acts as IRBC	Yes/No		No	
IRB Ambush Alarm Enabled	Yes/No	No	No	Yes
IRB Ambush Alarm Holdoff Time	Minutes	1	1	255
IRB Break-In Alarm Enabled	Yes/No	No	No	Yes
IRB Alarms Output	B, C, P, S, L✳		Buzzer	
Diagnostic Screen Enabled	Yes/No		No	
Test Pushbutton Enabled	Yes/No		Yes	
Remote Menu Locked	Yes/No		No	
Helix Mode Disabled★	Yes/No		Yes	
IRBO Starts Wireless★	Yes/No		Yes	
IRBC Starts Wireless★	Yes/No		Yes	
LCK Starts Wireless★	Yes/No		Yes	
Operator	VC, VX, VN		VC	

* Settings are fixed across standards

✳ C, O (Gate Lock Location) - Closed, open

* H, mm, s (Courtesy Light Time) - Hours, minutes, seconds

☆ Crt, A, B, C (Courtesy Light Profile) - Courtesy, Profile A, Profile B, Profile C

◇ C, O (SAF COM tests which beams) - Closing, opening

✳ B, C, P, S, L (IR Alarms Output) - Buzzer, Courtesy Light, Safe Common, Solenoid, LED

★ Settings are not configurable via the GUI

26. Description of Terminal Functions

S Sens1	Slave Motor (MTR S). Connects to the thin PURPLE wire of the Slave Motor.
S Sens2	Slave Motor (MTR S). Connects to the thin BLUE or ORANGE wire of the Slave Motor.
M Sens1	Master Motor (MTR M). Connects to the thin PURPLE wire of the Master Motor.
M Sens2	Master Motor (MTR M). Connects to the thin BLUE or ORANGE wire of the Master Motor.
Sens +	Operator sensor power connection. A 5V output for connecting to the thin RED sensor wire on both the MTR M and MTR S operators.
Sens -	Operator sensor power connection. A 0V output for connecting to the thin BLACK or GREY sensor wire on both the MTR M and MTR S operators.

Safe CLS Closing edge safety input. (A normally-closed potential-free input.) As long as a connection between this input and Com is maintained the controller will behave normally. When this connection is broken it will prevent the gate from closing if it is stationary, and will stop and reverse the gate if it is closing. This input has no effect if the gate is opening.



If the Safe CLS function is not required a link must be fitted between Safe CLS and Com for the controller to operate normally.†

Safe OPN Opening edge safety input. (A normally-closed potential-free input.) For as long as a connection between this input and Com is maintained the controller will behave normally. When this connection is broken it will prevent the gate from opening if it is stationary, and will stop and reverse the gate if it is opening. This input has no effect if the gate is closing.



If the Safe Open and reverse functions are not required a link must be fitted between safe Open and Com for the controller to operate normally.†

† When setting up the controller for the first time or after a full reset back to the Factory Default has been performed, the system will electronically override the Safety Inputs and allow the system to function without the links. However if safeties are connected to either or both inputs, thereafter there must be a normally-closed circuit maintained for the system to operate correctly. I.e. if Safety Beams are fitted and then removed, the circuit which is affected must be replaced with a wire link to create a normally-closed circuit.

LCK/STP Holiday Lockout or gate stop input. (A normally-closed potential-free input.) For as long as a connection between this input and Com is maintained the controller will behave normally. But, when this connection to Com is broken all inputs are inhibited, and if the gate is moving it will stop.



If the LCK function is not required a link must be fitted between LCK and Com.

TRG	Trigger input. (A normally-open potential-free input.) Momentarily connecting this input to Com will cause the gate to open or close depending on the operating mode selected. For more information see the Autoclose feature and Modes of Operation.
PED	Pedestrian Opening input. (A normally-open potential-free input.) Momentarily connecting this input to Com will cause one gate to open to the Pedestrian open position. For more information refer to the Pedestrian feature.
FRX	Free-exit input. (A normally-open potential-free input.) Momentarily connecting this input to Com will cause a gate which is closed, or closing, to open or re-open. If the gate is open, or opening, the signal has no effect other than to reset the Autoclose Timer (if selected.) Free-exit (FRX) never initiates a closing cycle. The only way to close a gate, if only the FRX input is used, is to activate the Autoclose feature on the controller.
LIT	LIT Activates the Pillar Light output. (A normally-open potential-free input.) Momentarily connecting this input to Com will cause the LIGHT relay to energise for a period of time as set in the Courtesy Light Timer menu. If the connection is made for a period exceeding 3 seconds the Pillar Light Relay will latch and remain latched indefinitely until a new momentary connection to Com is given.
LED	External gate status indicator. (A low-current output signal.) An output terminal which provides a low-current drive (approx. 4.5V DC, 20mA) to a LED which can be used to indicate the gate status remotely. If more than three LEDs are required it is necessary to fit the CP78 MULTI-LED driver card. For more details on the feedback about the status of the gate provided by the Status LED refer to page 72.
Com	The Common termination point. All trigger signals etc. have their return path to one of the Com terminals.
Aux 12V	Auxiliary power connection. Provides a +12V DC supply for auxiliary equipment such as a radio receiver, Safety Beams, etc. It is linked directly to the battery positive via a 3A resettable fuse.
Safe Com	Used for switching the power supply to the safety beam. If automatic beam testing is required, the negative power supply connection of the beam transmitter must be wired to this point.
Sol	Solenoid strike or magnetic lock. A solenoid strike lock or magnetic lock can be connected between 12V and Sol. Note that the maximum current draw allowed for the lock is 2A. Should the solenoid lock or magnetic lock exceed this current rating it is necessary to use an interposing relay. Particularly with magnetic locks, ensure that the steady state current draw calculated over a 24 hour period and added to this, the quiescent current draw of the controller, other peripherals and the usage of the motors, does not exceed the current delivered by the charger. If necessary, fit a separate supply to power the lock using an interposing relay connected to the Sol input.



Light	Pillar Light connection. These two terminals provide a normally-open potential-free contact which is generally used to switch on a Pillar Light (Courtesy Light). This contact is fuse-protected – refer to page 46 for fuse specifications.
Batt +	Positive battery connection. (Battery terminal normally indicated as + or RED)
Batt -	Negative battery connection. (Battery terminal normally indicated as - or BLACK)
MTR M+	Master Motor power connection. (Thick BLUE wire)
MTR M-	Master Motor power connection. (Thick BLACK wire)
MTR S+	Slave Motor power connection. (Thick BLUE wire)
MTR S-	Slave Motor power connection. (Thick BLACK wire)

27. Diagnostics

Diagnostic LEDs

The controller is fitted with diagnostic lights (LEDs) that assist with the setup and maintenance of the gate.

Figure 82 below provides the description and purpose of the indicator lights also indicating the location on the controller




FIGURE 83.

Gate Status LED Indication

Slow regular flash	Gate is opening
Fast regular flash	Gate is closing
One flash every two seconds	Courtesy Light latched on
Two flashes every two seconds	Mains Failure
Three flashes every two seconds	Battery-low
Four flashes every two seconds	Collision Shutdown
Four flashes every two seconds	Multiple Collisions have occurred

LCD Display

The LCD display shows useful information regarding the status of the system.




FIGURE 84. CONTROLLER SCREEN

1. Battery icon

Indicates the state of charge of the battery:

- Four solid bars = full capacity
- Two solid bars = 50% capacity
- No solid bars, with the icon flashing = battery empty

2. Mains icon

Displays the presence/absence of mains voltage:

- Plug solid = mains present and battery charging
- Plug hollow and flashing = No mains present and battery not charging

3. Autoclose information

- Displays the state of the Autoclose function
- Displays off if Autoclose is not selected
- OVR if Autoclose is overridden, and the remaining Autoclose time if Autoclose is active
- POVR indicates that the PIRAC option is overridden

4. Pillar Light information

- Displays the remaining light time if Courtesy Light Mode is selected
- Pre-flashing Mode is displayed if Pre-flash is selected
- LIT will be indicated if the Pillar Light has been turned on permanently

5. Onboard receiver information

Displays the current input being activated by the onboard receiver

6. Status information

Displays useful information regarding the status of the gate

Buzzer Feedback

The **VECTOR2** controller is equipped with an onboard buzzer which is used for various features and functions on the controller. One of the functions it provides is audible diagnostic feedback as detailed

Inhibitor name	Priority	Number of beeps	Fault type	Gate continues to operate	User can correct error
Break-in Alarm	1	Continuous tone for 30 seconds	Alarm	N/A	N/A
Ambush Alarm	2	Continuous tone until IRBs are cleared	Alarm	N/A	N/A
Battery-low	3	3 beeps periodically for 30 seconds	Power system fault	Yes [♦]	Yes
Multiple Collision	4	Periodic until condition is cleared by user (500/500ms)	Collision	No	Yes
Auxiliary Overload	5	5 beeps periodically for 30 seconds	Hardware	No	No
Holiday Lockout	6	1 beep periodically for 30 seconds	User	No	Yes
Emergency Stop	7	1 beep periodically for 30 seconds	User	No	Yes
Time-barring	8	1 beep periodically for 5 seconds	User	No	Yes
No Limits set	9	3 short beeps for 5 seconds	Lost	No	Yes
Mains Failure	10	2 beeps periodically for 30 seconds	Power system fault	Yes	Yes
Beams broken (any)	11	1 beep periodically for 30 seconds	User	No	Yes
Safety Beams Failure	12	5 beeps periodically for 30 seconds	Hardware	No	No
DOSS disconnected	13	5 beeps periodically for 30 seconds	Hardware	No	No
Fuse Blown	14	5 beeps periodically for 30 seconds	Hardware	No	Yes
Motor Disconnected	15	5 beeps periodically for 30 seconds	Hardware	No	Yes
Bridge Damaged	16	5 beeps periodically for 30 seconds	Hardware	No	No
Gate Stalled	17	4 beeps periodically for 10 seconds	Collision	No	Yes

[♦] Gate will close fully and then shut down for two minutes

28. Installation Handover

Once the installation has been successfully completed and tested, it is important for the installer to explain the operation and safety requirements of the system.

NEVER ASSUME THE USER KNOWS HOW TO SAFELY OPERATE AN AUTOMATED GATE!

Even if the user has used one before, it does not mean he knows how to SAFELY operate it. Make sure that the user fully understands the following safety requirements before finally handing over the site.

The following needs to be understood by the user:

- How to operate the manual release mechanism. **(Show them how by demonstration)**
- How the obstruction detection and all other safety features work. **(Show them how by demonstration)**
- All the features and benefits of the operator, i.e. Beams, etc.
- **All the safety considerations associated with operating an automated gate. The user should be able to pass this knowledge on to all other users of the automated system and must be made aware of this responsibility.**



- **Do not activate the gate operator unless you can see it and can determine that its area of travel is clear of people, pets, or other obstructions**
- **NO ONE MAY CROSS THE PATH OF A MOVING GATE. Always keep people and objects away from the gate and its area of travel**
- **NEVER LET CHILDREN OPERATE OR PLAY WITH THE GATE CONTROLS, and do not allow children or pets near the gate area**
- **Be careful with moving parts and avoid close proximity to areas where fingers or hands could be pinched**
- **Secure all easily-accessed gate operator controls in order to prevent unauthorised use of the gate**
- **Keep the automated gate system properly maintained, and ensure that all working areas are free of debris and other objects that could affect the gate operation and safety**
- **On a monthly basis, check the obstruction detection system and safety devices for correct operation**
- **All repair and service work to this product must be done by a suitably qualified person**



This product was designed and built strictly for the use indicated in this documentation. Any other use, not expressly indicated here, could compromise the good condition/operation of the product and/or be a source of danger!

Centurion Systems (Pty) Ltd does not accept any liability caused by improper use of the product, or for use other than that for which the automated system was designed.

Ensure that the customer is in possession of the User Guide and that you have completed the installation details in the back of the User Guide.

Notes

A series of horizontal dotted lines for writing notes.



Notes

A series of horizontal dotted lines for writing notes.





 facebook.com/CenturionSystems

 YouTube.com/CenturionSystems

Subscribe to the newsletter: www.CentSys.com/Subscribe

Sharecall 0860-CENTURION (0860 236 887)
Head Office: +27 11 699 2400

Sharecall Technical Support 0861 003 123 or
+27 11 699 2481
from 07h00 to 18h00 (GMT+2)

(Sharecall numbers applicable when dialed from within South Africa only)



0.07.A.0012_19052014

www.CentSys.com